

## ZipShot® Carrying Cases



**A126**  
**ZipShot® Carrying Case**  
 Internal: 4 W x 17 H (10 x 43cm)  
 External: 4½ W x 18 H (11 x 46cm)  
 Color: Black  
 Weight: 1.8 oz. (51g)

**A124**  
**ZipShot® Mini Carrying Case**  
 Internal: 4 W x 10½ H (10 x 27cm)  
 External: 4½ W x 11½ H (11 x 29cm)  
 Color: Black  
 Weight: 1.4 oz. (40g)

The ZipShot® and ZipShot® Mini Carrying Cases allow the tripods to be conveniently attached to the shoulder strap of a camera bag or to the MAS™ attachment slots found on many Tamrac products.



## Quick-Release ZipShot® Accessory Kit



**A120**  
**Quick-Release ZipShot® Accessory Kit**  
 Color: Gray  
 Weight: 1 oz. (28g)

Allows quick attachment and removal of any point & shoot camera or DSLR up to 3 lbs. (1361g) that has a ¼-20 tripod screw insert.



# ZIPSHOT®

COMPACT, ULTRA-LIGHT TRIPODS  
 Spring Open in Seconds



TAMRAC, INC.  
 9240 Jordan Avenue, Chatsworth, Ca 91311, USA  
 (818) 407-9500 Toll Free (800) 662-0717  
 FAX (818) 407-9501

For more information and product videos visit:  
[www.zipshottripod.com](http://www.zipshottripod.com)

©2011 Tamrac, Inc. Patent Pending Printed in USA No.150  
 Design, specifications and availability subject to change without notice.

# ZIPSHOT®


COMPACT, ULTRA-LIGHT TRIPODS  
 Spring Open in Seconds



**THE  
 PERFECT  
 TRAVEL  
 TRIPODS**



**1** To use, simply release the two red cords.



**2** Tripod legs spring open in seconds.

**3** Mount a camera and you're ready to shoot.



## The Perfect Travel Tripods

Most tripods are heavy, difficult to carry and slow to set up, which causes many missed photo opportunities. The ZipShot® and ZipShot® Mini tripods are the answer to this problem. Just release the two red cords and the legs of the ZipShot® and ZipShot® Mini spring open in seconds. Attach your camera and you're ready to shoot.

The ZipShot® and ZipShot® Mini are ultra-lightweight and ultra-compact. Both are constructed of sturdy, high-quality aluminum with a heavy-duty, metal ball-head and will hold a DSLR with a lens attached (up to 3 lbs. total weight), point & shoot cameras, most camcorders, and flashes. A single release lever allows the camera to be positioned at any angle so vertical and horizontal shots are easy.

With the ZipShot® and ZipShot® Mini tripods, you can capture the great shots you've been missing.

Visit [www.zipshottripod.com](http://www.zipshottripod.com) to see a video demonstration.



**ZipShot®**

**ZipShot®  
Mini**

### TR406 ZipShot® Tripod

Folded: 15" (38cm)  
Extended: 44" Tall (112cm)  
Color: Black  
Weight: 11 oz. (312g)

### TR404 ZipShot® Mini Tripod

Folded: 9" (23cm)  
Extended: 28" Tall (71cm)  
Color: Black  
Weight: 9 oz. (255g)

Convenient to carry in a purse or tote.



Attaches to the handle of most camera bags or luggage.



Easily fits inside a small suitcase.



Fits in the side pockets of many camera bags.



Fits inside most bags that can hold a telephoto lens.